Installation Instruction



Product Code: CLIFFEXITBOXUP

Product Description: Single Side LED Exit Sign











Specification

Emergency Power: <4W

Viewing Distance: 30M(EU) / 24M(AU)

EM Duration: 1H/3H/8H Charging Time: 24 hours Ambient Temp: 5-45°C Emergency Mode: Maintained Function: Standard/Self Test

Battery: LiFePO4 3.2V 1.5Ah

Guarantee: 3 Years











Routine Testing

Testing should be carried out in accordance with the recommendations of BS5266 & EN50172.

- 1. Do not switch off unswitched mains supply after installation. If interruption is unavoidable, the batteries must be disconnected or damage to the batteries may occur. Leave the luminaire on continuous charge for 24 hours.
- 2. A monthly functional test should be conducted manually.
- 3. Annually, a full three hour duration test should be conducted manually.
- 4. Batteries should be replaced when the luminaire no longer meets the 3 hours duration performance.
- 5. Testing is performed by interrupting the unswitched supply for the test duration manually or self-test function complying with IEC62034.

During testing the luminaire should remain illuminated in emergency mode.

- 6. Ensure that the 'charge indicator' is 'ON' during 'Charging Mode'. If the charge indicator (LED) is unlit, this signifies a fault.
- 7. Replace faulty light source and batteries immediately.

To assist with this testing, a test record is included below.


To increase the chance of a fault being reported between monthly tests, it is desirable that staff are made aware of the purpose of the indicator.

Testing Record


Product: _ Installation Date: Location:___

Month	Functional/Duration	Year 1	Year 2	Year 3	Year 4	Year 5
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						
11						
12						

Installation Instruction



Installation Instruction



Pictogram Replacement

