




Button overview




Resetting the system

To fully reset this unit press the recessed **RESET** button with an insulated blunt probe.

A full display will show when the battery is charged, then revert to the default screen (--:--).

No display indicates that the battery requires charging for a minimum 3 hour period.




Setting the correct time of day

1. Press and hold the **CLOCK** button (the day will flash)
2. Press + or - to select the correct day.
3. Press the **CLOCK** button to confirm the correct day.
4. **HOURS** will then flash, press + or - to select the correct hour. Press **CLOCK** button to confirm.
5. **MINUTES** will then flash, press + or - to select the correct minute. Press **CLOCK** button to confirm.

Setting up a program

1. Press and hold **PROGRAM** button for approx 3 seconds (this will take you to another screen).
2. Press + or - to select individual day (Mon). 7 day block (Mon-Sun) or 5 day block (Mon-Fri) you want the program to run on.
3. Press **PROGRAM** button to confirm the correct day/day block. (If individual day has been selected, each day will have its program set individually. MON followed automatically in programming by each of the other days).
4. **PROG 1** (on time) will appear. **HOURS** will flash, press + or - to select the correct hour. Press **PROGRAM** button to confirm.
5. **MINUTES** will then flash, press + or - to select the correct minute. Press **PROGRAM** button to confirm.
6. **PROG 1** (off time) will appear. **HOURS** will flash, press + or - to select correct hour. Press **PROGRAM** button to confirm.
7. **MINUTES** will flash, press + or - to select the correct minutes. Press **PROGRAM** button to confirm. **PROG 2** (on time) will appear. Repeat steps 4 to 7. Repeat the same steps for **PROG 3 & 4**.



If no other program is required keep pressing the **PROGRAM** button to revert back to homescreen (current time).

Setting timer status

NOTE: Operating mode needs to be set to allow programmed times to function.

Use '+ ' Button to set the output mode.

1. **ON** - Output permanently **ON**.
2. **OFF** - Output permanently **OFF**.
3. **AUTO OFF** - If the current time is outside your programmed time you need to set the timer status to **AUTO OFF**. This means the output to your appliance is **OFF** until your next programmed **ON** time.
4. **ON AUTO** - If the current time is within your programmed time you need to set timer status to **ON AUTO**. This means the output to your appliance is **ON** until your next programmed **OFF** time.

Remember, when in program mode, the display will always show 'AUTO'.


Boost function

This function will enable you to switch **ON** when outside any of your programme settings without affecting your programs.

1. Press - button **ONCE** during the normal operating mode to turn output on for a **1 HOUR PERIOD**.
2. Press - button **TWICE** during the normal operating mode to turn output on for a **2 HOUR PERIOD**.
3. Press - button **3 TIMES** to cancel the Boost function.

Programme Example

On at 6pm - Off at 10pm every day of the week Set 1 On to 1800 not 18-- and 1 Off to 2200 with all days of week showing.
Remaining unused programmes set to 0000 or ----
Then follow 'Setting Timer Status' section.



NOTE:

To turn off the output of the timer please press the + button until you see the 'OFF' symbol beneath the clock settings. When turning the timer back on please follow the procedure as shown on section 'SETTING TIMER STATUS'.

The isolator switch on the timer should not be turned off for long periods as this could cause loss of programme settings.